



JMA DAS Platform Local Commissioning User Guide

DAS Supervision Version: 4.3.4

Document Version: 5

Date: February 2024



Legal Notices

© 2024 John Mezzalingua Associates, LLC dba JMA Wireless. All rights reserved.

This document may contain confidential and/or proprietary information. All company names, brands, and logos are trademarks of holders JMA Wireless or its affiliates. All specifications are subject to change without notice.

World Headquarters

JMA Wireless

140 Cortland Ave.

Syracuse, NY 13202

+1 888 201-6073

customerservice@jmawireless.com

For additional contact information, see the JMA Wireless website:

jmawireless.com

Table of Contents

About this Guide	4
What's New	4
DAS Commissioning	5
Accessing the DAS Supervision Module Web Interface Locally	7
Discovering the DAS Components	9
Modifying the System Name and Description	11
Assigning Names to the DAS Components	12
Setting the TDD Sync Module	13
Selecting the NG OTRX Simulcast Configuration	15
Adjusting the Next Generation Point-to-Point Link RF Gain	17
RF Commissioning of Points of Interface and Remote Units	19
RF Commissioning of Donor Front Ends (TDFEs)	31
Enabling Downlink RF Power Alarms	33
Setting External Alarms and Relays	34
Setting Alarm and Heartbeat Notifications	37
Setting the Network Security	41
Setting the System Date and Time	42
Setting Options for Testing the Network Connection	43
Setting the Supervision Module Communication Interface for Remote Management	44
Managing Users	47
Creating and Managing Inventory Lists	49
Getting Help: Technical Support Contact Information	52
Abbreviations	53

About this Guide

The DAS (Distributed Antenna System) supervision module web interface allows the monitoring, configuration, and commissioning of all the components managed by the DAS supervision module.

This document guides users with **admins** capabilities through the commissioning process of JMA distributed antenna systems (DAS).

Refer to the *JMA DAS Platform Remote Monitoring and Management User Guide* for detailed descriptions of the DAS supervision module web user interface, monitoring features, and configuration options.

What's New

This revision (rev.5) of the *JMA DAS Platform Local Commissioning User Guide* describes release 4.3.4 of the DAS supervision module, which adds support for the following new products:

- Next generation components, which operate in the 3400–3800MHz frequency band (35I, N43):
 - ED35ID, next generation optical transceiver (NG OTRX).
 - ED35IDM and ED35IDS, next generation Master and Secondary Point-to-Point rack-mount units (NG PtoP).
 - RD35IWX2AT and RD35IWX2DT, single-band 10/20/40W, MIMO, next generation, Software Defined Remote Units (NG SDRU).
- TCPRIPOI-23T-M-N CPRI Point of Interface, which operates in the 2300–2400MHz frequency band (TCPRIPOI).

Release 4.3.4 of the DAS supervision module also introduces:

- The *PSU High Temperature* alarm, which is available for Next Generation Remote Units (NG RU) and Software Defined Remote Units (NG SDRU).
- The WAN *MTU* parameter, which allows configuration of the Maximum Transmission Unit for the Supervision Module WAN Interface. See ["Setting the WAN Interface" on page 44](#).

This revision of the *JMA DAS Platform Local Commissioning User Guide* guide also includes instructions for adjusting the RF gain of the Next Generation Point-to-Point link. See ["Adjusting the Next Generation Point-to-Point Link RF Gain" on page 17](#).

DAS Commissioning

Note: Before commissioning, complete the DAS installation and power-up, as described in the JMA DAS Platform installation guides:

- *JMA DAS Platform Master Unit Installation Guide*
- *JMA DAS Platform Remote Units Installation Guide*
- *JMA DAS Platform Next Generation Remote Units Installation Guide*

If the supervision module is equipped with the optional wireless modem, before start-up, insert the SIM card, enabled for data transfer and preferably unlocked (PIN code disabled).

The following are the steps required in the commissioning process:

1. Access the DAS web interface locally. See ["Accessing the DAS Supervision Module Web Interface Locally" on page 7](#).
Note: When the DAS includes next generation point-to-point links, the DAS components installed at the master unit location and the DAS components installed at the remote location are managed by two separate supervision modules. You need to connect to the supervision modules separately to complete the commissioning of the entire DAS.
2. Find and identify the DAS components. See ["Discovering the DAS Components" on page 9](#).
3. Modify the system name and description and assign descriptive names to the DAS components to make management easier.
See ["Modifying the System Name and Description" on page 11](#) and ["Assigning Names to the DAS Components" on page 12](#).
4. In TDD networks, set the frame structure of the TDD sync module according to the base station TDD configuration. See ["Setting the TDD Sync Module" on page 13](#).
5. Select the proper NG OTRX simulcast configuration according to the system design. See ["Selecting the NG OTRX Simulcast Configuration" on page 15](#).
6. If required by the system design, set the Next Generation Point-to-Point link RF gain. See ["Adjusting the Next Generation Point-to-Point Link RF Gain" on page 17](#).
7. Set the parameters for the RF commissioning of points of interface (POIs) and remote units.
See ["RF Commissioning of Points of Interface and Remote Units" on page 19](#).
8. Check that all downlink RF power alarms are enabled. See ["Enabling Downlink RF Power Alarms" on page 33](#).
9. Set external alarms and relays. See ["Setting External Alarms and Relays" on page 34](#).
10. Set heartbeats and alarm notifications. See ["Setting Alarm and Heartbeat Notifications" on page 37](#).

11. Configure the following:

- Network security. See ["Setting the Network Security" on page 41](#).
- DAS date and time. See ["Setting the System Date and Time" on page 42](#).
- Options for testing the network connection. See ["Setting Options for Testing the Network Connection" on page 43](#).

12. Configure the supervision module remote communication interface to allow remote management of managed components. See ["Setting the Supervision Module Communication Interface for Remote Management" on page 44](#).

13. Change the factory-set passwords and manage user accounts. See ["Managing Users" on page 47](#).

14. Create an inventory list to back up the current DAS configuration. See ["Creating and Managing Inventory Lists" on page 49](#).

Accessing the DAS Supervision Module Web Interface Locally

1. Connect your laptop to the **LAN** port, available on the front panel of the DAS supervision module.



Note: When the DAS includes next generation point-to-point links, the DAS components installed at the master unit location and the DAS components installed at the remote location are managed by two separate supervision modules:

- The supervision module, which manages the DAS components installed at the Master Unit location, including the next generation point-to-point master component.
- The remote supervision module, which manages the DAS components installed at the remote location, including the next generation point-to-point secondary component, distant optical transceivers, and all connected remote units.

You need to connect to the supervision modules separately to complete the commissioning of the entire DAS.

2. Check that your laptop is configured to automatically obtain the IP address from the supervision module's built-in DHCP server.
3. Start a web browser.

Note: In the web browser options it is advisable to set the security level to medium (or lower) and disable the pop-up blocker, to correctly display the web interface.

4. In the URL bar, type the factory-set local DAS IP address: **192.168.1.100**.
5. Click **Enter** for login.



6. Enter the factory-set username and password of the **admins** account:

User name: **admin**

Password: **Password1**

7. Click **Login (full)**.

▸ **Access Denied**

If access is denied, check the username and password spelling, then log in with the correct details.

Note: Username and **Password** fields are case-sensitive. Make sure to type the username and password with correct upper-case and lower-case letters.


▸ **Successful Login**

After successful login, the user interface opens with the **System** panel displayed.


Discovering the DAS Components

To manage the physical components connected to the supervision module they must first be identified.

1. In the **Settings** menu, select **Discovery** to open the **Discovery** panel.



2. In the **Discovery** panel, click **Discovery full**.



3. In the **Please Confirm** dialog box, click **Proceed**.


If the discovery process is successful, the hierarchical architecture of the DAS components displays in the **New Tree** pane.

4. Verify that all expected components are listed in the tree.

If not all expected devices are found by the discovery, check connections and power supply, then repeat the discovery.

5. Click **Accept discovery** to accept the discovery.

The supervision module uploads the names of all the detected components and the **Full discovery** dialog box displays.



6. In the **Full discovery** dialog box, click **Ok** to complete the discovery.

DAS Commissioning

Note: The discovery must be accepted to unlock the supervision system. Only after the full discovery is accepted, inventory lists and alarm logs, if any, are cleared, and the supervision module starts collecting the DAS alarms.

The discovered DAS physical components are populated in the **Physical Tree** only after the discovery is accepted. A progress bar below the **Physical Tree** indicates the progress of the operation.

Modifying the System Name and Description

1. Select the root node at the top of the **Physical Tree** to open the **System** panel.

The root node is identified by this icon: .

2. In the **System Description** pane, enter the new name and description.

System description	
Name	<input type="text" value="SystemName"/>
Description	<input type="text" value="System-Description"/>

The following characters are allowed:

- Lowercase letters (a through z)
- Uppercase letters (A through Z)
- Base 10 digits (0 through 9)
- Hyphen (-) and underscore (_)

The application input validation feature warns users if invalid characters are entered and details what input is expected for the field.

The **Save** tool in the toolbar and the background of modified fields turn yellow to highlight unsaved changes.

3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to assign the new name and description to the DAS. The new system name is displayed in the **Physical Tree**.

Assigning Names to the DAS Components


1. In the **Physical Tree**, select the component to display its details panel.
2. In the **Name** field, type a descriptive name for the node.

The following characters are allowed:

- Lowercase letters (a through z)
- Uppercase letters (A through Z)
- Base 10 digits (0 through 9)
- Hyphen (-) and underscore (_)

The application input validation feature warns users if invalid characters are entered and details what input is expected for the field.

The **Save** tool in the toolbar and the background of modified fields turn yellow to highlight unsaved changes.



3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to assign the new name to the DAS component. The name assigned to the component is displayed in the **Physical Tree**.

Note: The names of active points of interface (POIs) and remote units can be set either individually, in each component panel, or globally, accessing the Massive Change Menu. See "[RF Commissioning of Points of Interface and Remote Units](#)" on page 19.

Setting the TDD Sync Module

Note: The proper setting of the TDD sync module frame structure is crucial to optimal DAS performance in TDD networks.

1. In the **Physical Tree**, select the TDD sync module to display its details panel.

2. Configure the frame structure as follows:

▪ **4G Systems (TSYNC Module)**

Sync Frame Structure			
TDD device version	1.4	Configuration	3
		Special Frame	8

In the **Sync Frame Structure** pane, select *Configuration* and *Special Frame*, according to the BS TDD configuration:

- **Configuration.** Select the TDD downlink-uplink configuration (0-6), which defines how subframes are distributed between uplink and downlink, and the switch-point periodicity.
- **Special Frame.** Select the subframe configuration (0-8), which defines the length of the Guard period, Downlink Pilot Time Slot, and Uplink Pilot Time Slot.

▪ **5G Systems (TSYNC-N, TSYNC-C Modules)**

5G/NR Frame Structure			
TDD device version	4.6	SSB filter width	4
Subcarrier spacing [kHz]	15 ▼	Holdover time [minutes]	5
SSB position	0 ▼		
Pattern 1 enabled	<input checked="" type="checkbox"/>	Pattern 2 enabled	<input type="checkbox"/>
DL/UL Pattern 1 duration [ms]	10 ▼	DL/UL Pattern 2 duration [ms]	10 ▼
Nbr of DL slots Pattern 1	6	Nbr of DL slots Pattern 2	4
Special slot DL symbols Pattern 1	11	Special slot DL symbols Pattern 2	0

In the **5G/NR Frame Structure** pane, set the 5G/NR frame structure, according to the BS TDD configuration:

- Select the **Subcarrier spacing [kHz]**: 15kHz, 30kHz, or 60kHz.
- Select the **SSB Position**, that is the position in time of the SSB (Synchronization Signal Block) Carrier. Only one SSB Position per Pattern1+Pattern2 is supported.
- Optional: Enable **Pattern 2**. Pattern 1 is enabled by default. An additional synchronization pattern (Pattern 2) can be enabled.
- Select the duration (**DL/UL Pattern 1 duration**, **DL/UL Pattern 2 duration**).
- Set the number of downlink slots per pattern (**Nbr of DL slots Pattern 1**, **Nbr of DL slots Pattern 2**). **Note:** Each slot is made of 14 symbols in time domain.
- Set the number of DL symbols defined in the Special Slot Format (**Special slot DL symbols Pattern 1**, **Special slot DL symbols Pattern 2**). Refer to ETSI TS 38.213 Release 15, Table 11.1.1-1 for details.

DAS Commissioning

- Set the **Holdover time [minutes]**, that is the time for which the TSYNC module will remain in a sync status even if the signal from the BS is absent.
Note: At least 10 minutes of past lock are required.
- Set the SSB filter width.

3. In the **Attenuations** pane, adjust the attenuation for each channel to compensate for the reference output signal path losses.

The **Attenuations** pane is available for the **TSYNC**, **TSYNC-N**, and **TSYNC-X** modules.

The attenuation to be removed is related to the passive combining on the DAS.

Note: The **TSYNC** and **TSYNC-X** module factory-set attenuation is 19dB. The **TSYNC-N** module factory-set attenuation is 26dB.

Attenuations			
Att Channel 1	<input type="text" value="19.25"/>	Att Channel 3	<input type="text" value="19.25"/>
Att Channel 2	<input type="text" value="19.25"/>	Att Channel 4	<input type="text" value="19.25"/>

4. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save all the changes in the page.

Selecting the NG OTRX Simulcast Configuration

1. In the **Physical Tree**, select the NG OTRX to display its details panel.

1.2.1 NG OTRX (ED35BD)

Optical Transmitter/Receiver for Master Unit, Auction 110, MIMO 2x2, 4 Sectors 8OUT, WDM

Identification		Alarm summary	
Type hex	00005C	Communication state	●
Model hex	000000000002	Max severity	●
Version	1.2.0.58	Active Alarms	2
Serial Number	1043643004		

Parameters			
Board Temperature [°C]	40	Low Temperature	●
Core Temperature [°C]	67.3	High Temperature	●
		Mains Fault	●
		TDD Unlock	●
		Clock Distributor Unlock	●
		Init Failure	●

RF Path Mapping

Configuration: Configuration 1

A1 - 1.2.1.1		A2	
Opt. Link state	LC fiber	Rx Optical Low A1	●
SFP Temperature [°C]	54.4	Loss of Sync A1	●
Opt. Power Tx [dBm]	-0.3	RU Type Mismatch A1	●
Opt. Power Rx [dBm]	-3.6	RU1 addr: fe80::1a45:b3ff:fe90:71e	
		Alarm summary RU1	●

RF Path A			
Attenuation UL1 [dB]	0	Attenuation DL1 [dB]	0
RMS Power Max A UL1	●	Overdrive A DL1	●
Current A UL1	●	RMS Power Max A UL2	●
		Overdrive A DL2	●
		Current A UL2	●

B1		B2	
Opt. Link state	Absent	Rx Optical Low B1	●
SFP Temperature [°C]	-128	Loss of Sync B1	●
Opt. Power Tx [dBm]	-70	RU Type Mismatch B1	●
Opt. Power Rx [dBm]	-70		
		Opt. Link state	Absent
		SFP Temperature [°C]	-128
		Opt. Power Tx [dBm]	-70
		Opt. Power Rx [dBm]	-70
		Rx Optical Low B2	●
		Loss of Sync B2	●
		RU Type Mismatch B2	●

RF Path B			
Attenuation UL1 [dB]	0	Attenuation DL1 [dB]	0
RMS Power Max B UL1	●	Overdrive B DL1	●
Current B UL1	●	RMS Power Max B UL2	●
		Overdrive B DL2	●
		Current B UL2	●

2. In the **RF Path Mapping** pane, select the proper simulcast configuration from the **Configuration** drop-down list or choose a diagram. The diagram describes how RF signal is distributed to the connected remote units (RF path mapping).

When you select a configuration from the drop-down list, the diagram that corresponds to the selected configuration is highlighted. You can choose between eight different simulcast configurations.

Note: Refer to the system design to select the appropriate configuration.

Configuration 1 is the default factory configuration. If *Configuration 1* (default) is selected, the highlighted *Conf. 1* diagram shows that the signal from four different MIMO 2x2 cells will be simulcast by the NG OTRX transceivers (A, B, C, D) to four different pairs of remote units, connected to the NG OTRX optical ports (A1, A2, B1, B2, C1, C2, D1, D2).

Note: Changing the simulcast configuration has no impact on the RF link: no attenuation adjustment is needed.

DAS Commissioning

In the *JMA DAS Platform Master Unit Installation Guide*, refer to *Connecting the Next Generation Optical Transceiver to the Next Generation Remote Units* for details about remote units and NG OTRX (Next Generation Optical Transceiver) connection.

3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to apply the selected configuration.

Adjusting the Next Generation Point-to-Point Link RF Gain

For each RF path (A, B, C, D), the overall RF gain of the Point-to-Point link is 0dB at default attenuation settings. The following table details the Next Generation Point-to-Point link default attenuation settings:

Next Generation Point-to-Point Component	Default Downlink Attenuation for each RF Path, MIMO1 layer	Default Downlink Attenuation for each RF Path, MIMO2 layer	Default Uplink Attenuation for each RF Path, MIMO1 layer	Default Uplink Attenuation for each RF Path, MIMO2 layer
NG PtoP Master	0dB (Attenuation Tx1)	0dB (Attenuation Tx2)	7dB (Attenuation Rx1)	7dB (Attenuation Rx2)
NG PtoP Secondary	14dB (Attenuation Rx1)	14dB (Attenuation Rx2)	0dB (Attenuation Tx1)	0dB (Attenuation Tx2)

If required by the system design, you can increase the Point-to-Point link RF gain as follows:

1. To increase the downlink RF gain for a specific RF path:
 - a In the **Physical Tree**, select the Next Generation Secondary Point-to-Point Component (NG PtoP Secondary).
 - b In the appropriate **RF Path** pane (RF Path A, RF Path B, RF Path C, RF Path D), reduce the *Attenuation Rx1* and *Attenuation Rx2* for the RF path. The following figure shows a detail of the NG PtoP Secondary panel with default RF attenuation settings:

The screenshot displays the configuration interface for the Next Generation Point-to-Point Secondary component, showing four RF Path panes (A, B, C, and D). Each pane contains the following settings:

- Attenuation Rx1**: 14 dB (light blue slider)
- Attenuation Tx1 [dB]**: 0 dB (light blue slider)
- Attenuation Rx2**: 14 dB (light blue slider)
- Attenuation Tx2 [dB]**: 0 dB (light blue slider)
- RMS Power Max**: Indicated by a green dot.
- Overdrive**: Indicated by a green dot.
- Current**: Indicated by a green dot.

2. To increase the uplink RF gain for a specific RF path:
 - a In the **Physical Tree**, select the Next Generation Master Point-to-Point Component (NG PtoP Master).
 - b In the appropriate **RF Path** pane (RF Path A, RF Path B, RF Path C, RF Path D), reduce the *Attenuation Rx1* and *Attenuation Rx2* for the RF path. The following figure shows a detail of the NG

PtoP Master panel with default RF attenuation settings:

RF Path A			
Attenuation Rx1 [...]	7	Attenuation Tx1 [dB]	0
Attenuation Rx2 [...]	7	Attenuation Tx2 [dB]	0
RMS Power Max A Rx1		Overdrive A Tx1	
RMS Power Max A Rx2		Overdrive A Tx2	
Current A Rx1		Current A Rx2	
RF Path B			
Attenuation Rx1 [...]	7	Attenuation Tx1 [dB]	0
Attenuation Rx2 [...]	7	Attenuation Tx2 [dB]	0
RMS Power Max B Rx1		Overdrive B Tx1	
RMS Power Max B Rx2		Overdrive B Tx2	
Current B Rx1		Current B Rx2	
RF Path C			
Attenuation Rx1 [...]	7	Attenuation Tx1 [dB]	0
Attenuation Rx2 [...]	7	Attenuation Tx2 [dB]	0
RMS Power Max C Rx1		Overdrive C Tx1	
RMS Power Max C Rx2		Overdrive C Tx2	
Current C Rx1		Current C Rx2	
RF Path D			
Attenuation Rx1 [...]	7	Attenuation Tx1 [dB]	0
Attenuation Rx2 [...]	7	Attenuation Tx2 [dB]	0
RMS Power Max D Rx1		Overdrive D Tx1	
RMS Power Max D Rx2		Overdrive D Tx2	
Current D Rx1		Current D Rx2	

3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

RF Commissioning of Points of Interface and Remote Units

The parameters for the commissioning of points of interface (POIs) and remote units can be set either individually, in each component panel, or globally, accessing the **Massive Change Menu**.

Setting Parameters Individually for Each Component

1. In the **Physical Tree**, select the component to display its details panel. Fields that can be edited by users have a light-blue background.

2. Modify parameters.

The **Save** tool in the toolbar and the background of modified fields turn yellow to highlight unsaved changes.

3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Setting Parameters with the Massive Change Menu

1. In the **Settings** menu, select **Massive Change Menu**. In the **Massive Change Menu** panel, active POIs and remote units are grouped by type. A **Massive Change** button is available for each type.

TDTPOI Massive Change

Click to open the Massive change table for the TDTPOIs in the System

TDTPOI List

List of the TDTPOIs in the System with links to each module web page

Massive Change Menu

Global parameter setting for commissioning of Active Point of Interface (POI) and SDRU

TAPOI

Massive Change

TAPOI List

TLPPOI

Massive Change

TLPPOI List

TDTPOI

Massive Change

TDTPOI List

- 1.4.2 TDTPOI
- 1.4.5 TDTPOI
- 1.4.8 TDTPOI
- 1.4.11 TDTPOI
- 1.5.12 TDTPOI
- 1.7.6 TDTPOI
- 1.7.11 TDTPOI

2. Click the **Massive Change** button to display the Massive Change table for all the components of the same type.

Note: A pop-up, indicating the progress of the loading process, may display.

If the process completes successfully, the pop-up closes and the Massive Change table is displayed.

If the pop-up reports errors, click **Ok**. The Massive Change table is displayed, but changes to the components listed in the pop-up are disabled. Click the **Reload** button to reload information and enable changes.

DAS Commissioning

Massive Change for TAPOI											
Massive Change for TAPOI											
Modules											
Address	Code	Name	DL att [dB]	UL att [dB]	DL RMS power [dBm]	DL RMS min [dBm]	DL RMS max [dBm]	Pwr Limiter mode	Hysteresis [dB]	Save	Reload
1.2.6	TAPOI-DCS-F	TAPOI-DCS-F	24	20	-7.7	10	27	10 dB plus	1		
1.10.5	TAPOI-AWF-F-4	TAPOI-AWF-F-4_58	30	30	-9.7	-4	11	10 dB isolated	2		
1.10.6	TAPOI-AWS	TAPOI-AWS_59	31	31	-9.9	-5	10	10 dB plus	1		
1.10.11	TAPOI-6-F-4	TAPOI-6-F-4_27	30	30.5	-6.3	-10	27	10 dB plus	1		
1.11.12	TAPOI-9PP-F-4	TAPOI-9PP-F-4_17	14	28	-7.5	-5	35	10 dB isolated	5		
1.12.12	TAPOI-SMR700H-F-4	TAPOI-SMR700H-F-4	30	44	-14.9	-15	20	10 dB plus	3		

3. Set configuration and parameters for each component.

4. Click the yellow save icon to save all changes for the module or place the cursor in any position in the row and press the **Enter** key on your keyboard.

Note: Changes must be saved for each module. A save icon is available for each row.

Massive Change for TDTPOI

Massive Change for TDTPOI

Modules

Address	Code	Preset	Name	Path	DL att mecc BTS [dB]	DL att dig BTS in [dB]	DL att dig DAS out [dB]	UL att dig BTS Main [dB]	UL att dig BTS Div [dB]	UL att dig DAS in [dB]	DL RMS power [dBm]	DL min RMS thrs [dBm]	DL max RMS thrs [dBm]	Pwr Limiter mode	Histeresys [dB]	Save	Reload
1.1.2	TDTPOI-23...	Dual SISC ▾	DAS Tray	1	0 ▾	0	0	0	0	0	-13	-10	36	10 dB plus ▾	2		
				2	15 ▾	0	0	0	0	-16.2	0	36					

Address

Component position in the DAS and link to the component web page

Modified setting

Yellow background: not yet saved changes

Yellow Save icon

There are unsaved changes to the module settings. If you exit the page changes will be ignored. Click the icon to save changes

Commissioning TAPOLs

1. In the **Settings** menu, select **Massive Change Menu**.
2. In the **TAPOL** pane, click the **Massive Change** button to display the Massive Change table for TAPOLs.

Massive Change for TAPOL											
Massive Change for TAPOL											
Modules											
Address	Code	Name	DL att [dB]	UL att [dB]	DL RMS power [dBm]	DL RMS min [dBm]	DL RMS max [dBm]	Pwr Limiter mode	Hysteresis [dB]	Save	Reload
1.2.6	TAPOL-DCS-F	TAPOL-DCS-F	24	20	-7.7	10	27	10 dB plus	1	Save	Reload
1.10.5	TAPOL-AWF-F-4	TAPOL-AWF-F-4_58	30	30	-9.7	-4	11	10 dB isolated	2	Save	Reload
1.10.6	TAPOL-AWS	TAPOL-AWS_59	31	31	-9.9	-5	10	10 dB plus	1	Save	Reload
1.10.11	TAPOL-6-F-4	TAPOL-6-F-4_27	30	30.5	-6.3	-10	27	10 dB plus	1	Save	Reload
1.11.12	TAPOL-9PP-F-4	TAPOL-9PP-F-4_17	14	28	-7.5	-5	35	10 dB isolated	5	Save	Reload
1.12.12	TAPOL-SMR700H...	TAPOL-SMR700H-F-4	30	44	-14.9	-15	20	10 dB plus	3	Save	Reload

3. In the Massive Change table, configure each TAPOL as follows:

- a Assign a name to the component.
- b Adjust uplink (UL) and downlink (DL) attenuation.

After successful completion of relevant training courses, use the commissioning tool spreadsheet, provide by JMA, to calculate uplink and downlink attenuation to be set.

Description	Massive change label	Default setting (maximum level)
Digital Attenuation DL	DL Att	31dB
Digital Attenuation UL	UL Att	31dB

- c Adjust the maximum and minimum input power thresholds for peak and rms detectors: DL RMS min and DL RMS max.

Refer to the following table for the relationship between the maximum input power and the minimum downlink attenuation to be set for the module.

Maximum input power	Minimum attenuation setting (DL Att)
26dBm	1dB
27dBm	2dB
28dBm	3dB
29dBm	4dB
30dBm	5dB
31dBm	6dB
32dBm	7dB
33dBm	8dB

- d** Select the power limiter mode to protect the module.

The following options are available in the **Pwr Limiter mode** drop-down list:

- *Disabled*: The power limiter is disabled.
- *10dB isolated*: When the Power Limiter Mode is set to *10dB isolated* and the downlink input signal exceeds the user-set maximum input signal threshold (*Max Peak Power* or *Max Rms Power*, depending on the threshold set in the Power Limiter drop-down list), the module enters auto power-off.
- *10dB plus*: When the Power Limiter Mode is set to *10dB plus* and the downlink input signal exceeds the user-set maximum input signal threshold, the signal is 10dB attenuated.

- e** Set the Power Alarm **Hysteresis** to avoid repeated power alarm reports.

If the input power (DL RMS power) exceeds the input power threshold set for the path (DL RMS max), the power limiter alarm is triggered.

The alarm is cleared when: $DL\ Rms\ Pwr\ [dBm] = DL\ RMS\ max\ [dBm] - Hysteresis\ [dB]$.

- 4.** Click the yellow save icon to save changes for each module.

Commissioning TLPPOs

1. In the **Settings** menu, select **Massive Change Menu**.
2. In the **TLPPOI** pane, click the **Massive Change** button to display the Massive Change table for TLPPOIs.

Massive Change for TLPPOI																
Massive Change for TLPPOI																
Modules																
Address	Code	Name	Path	Att mec DL [dB]	Att dig DL [dB]	Att dig UL [dB]	Rms IN Pwr DL [dBm]	Min Rms IN Pwr DL [dBm]	Max Rms IN Pwr DL [dBm]	Enable Power Amp.	Enable LNAin UL	Enable LNAout UL	Pwr Limiter mode	Histeresys [dB]	Save	Reload
1.10.12	TLPP0I-VB-MS	TLPP0I-VB-MS_03	1	10 ▼	5	5	-22.9	-30	15	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	10 d...	3		
			2	10 ▼	20	20.25	-21.7	-30	25	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	10 d...	3		
1.12.9	TLPP0I-LB-M...	TLPP0I-LB-MSE_16	1	10 ▼	25	20	-25.5	-99	0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	10 d...	2		
			2	10 ▼	15	20	-25.3	-26	10	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	10 d...	2		

3. In the Massive Change table, configure each TLPPOI as follows:

- a Assign a name to the component.
- b Adjust uplink and downlink attenuation for each path.

After successful completion of relevant training courses, use the commissioning tool spreadsheet, provide by JMA, to calculate uplink and downlink attenuation to be set.

Description	Massive change label	Default setting (maximum)
Mechanical Attenuation BS (Base Station) Side	Att mec DL	0dB
Digital Attenuation - Downlink path	Att dig DL	20dB
Digital Attenuation- Uplink path	Att dig UL	20dB

- c Adjust maximum and minimum input power thresholds for each path: Min Rms IN Pwr DL and Max Rms IN Pwr DL.
- d Select the power limiter mode to protect the module.

The following options are available in the **Pwr Limiter mode** drop-down list:

- **RF OFF:** If the Power Limiter Mode is set to *RF OFF*, when the rms downlink input power exceeds the user-set maximum input signal threshold (Max Rms IN Pwr DL) for the path (1 or 2), the Pwr Limiter DL (1 or 2) alarm is triggered and the path is switched off, until the alarm condition ceases (auto power-on).
- **10dB plus:** If the Power Limiter Mode is set to *10dB plus*, when the rms downlink input power exceeds the user-set maximum input signal threshold (Max Rms IN Pwr DL) for the path (1 or 2), the Pwr Limiter DL (1 or 2) alarm is triggered and the path input power is reduced by 10dB, until the alarm condition ceases.

Note: When the rms downlink input power (path 1 or 2) exceeds either the user-defined maximum input signal threshold Max Rms Power DL+10dB, or the allowed Absolute Maximum

DAS Commissioning

Input Power, the path (1 or 2) is switched off by the overdrive protection and the Pwr Overdrive DL (1 or 2) alarm is triggered.

The overdrive alarm needs to be cleared: when the alarm ceases, click the **Clear Overdrive** button to reset the path.

The path is restored @ max attenuations (Mec DL and Dig DL) and the re-commissioning of the path is required.

- e Set the Power Alarm **Hysteresis** to avoid repeated power alarm reports.

If the input power exceeds the maximum input power threshold set for the path, the power limiter alarm is triggered. The alarm is cleared when: $\text{Rms IN Pwr DL [dBm]} = \text{Max Rms IN Pwr DL} - \text{Hysteresis}$.

4. Click the yellow save icon to save changes for each module.

Commissioning TDTPOIs

1. In the **Settings** menu, select **Massive Change Menu**.
2. In the **TDTPOI** pane, click the **Massive Change** button to display the Massive Change table for TDTPOIs.

Address	Code	Name	Preset	Path	DL att mecc BTS [dB]	DL att dig BTS in [dB]	DL att dig DAS out [dB]	UL att dig BTS Main [dB]	UL att dig BTS Div [dB]	UL att dig DAS in [dB]	DL RMS power [dBm]	DL min RMS thrs [dBm]	DL max RMS thrs [dBm]	Pwr Limiter mode	Histeresys [dB]	Save	Reload
1.1.6	TDTPOI-35T...	DAS TRAY 25_35LL	MI...	1	15	10	0	10		10	-17.2	0	40	RF ...	2		
				2	15	17	0	20		0	-22.1	-20	36				
1.13.10	TDTPOI-19-S	TDTPOI-19-S	Sin...	1	15	15	0	25	25	0	-11.8	-10	30	RF ...	2		
				2	15	17	0	25	25	0	-11.6	-20	36				

3. In the Massive Change table configure each TDTPOI as follows:

- a Assign a name to the component.
- b Adjust uplink and downlink attenuation for each path.

After successful completion of relevant training courses, use the commissioning tool spreadsheet, provide by JMA, to calculate uplink and downlink attenuation to be set.

Description	Massive change label	Default setting (maximum)
Mechanical Attenuation BS (Base Station) Side	DL att mecc BTS	15dB
Digital Attenuation BS Side	DL att dig BTS in	17dB
	UL att dig BTS Main	25dB
	UL att dig BTS Div	25dB
Digital Attenuation DAS Side	UL att dig DAS in	0dB
	DL att dig DAS out	0dB

- c Adjust maximum and minimum input power thresholds for each path: DL min RMS thrs and DL max RMS thrs.

Refer to the following table for the relationship between the maximum input Power and the minimum downlink attenuation to be set for the path.


Minimum Downlink attenuation Mechanical	Maximum Input Power (no damage)		
	DAS Tray		Low Loss DAS Tray
	@40°C (+104°F) (*)	@55°C (+131°F) (*)	@55°C (+131°F) (*)
15dB	49dBm	47dBm	40dBm
10dB	46dBm	46dBm	36dBm
5dB	41dBm	41dBm	31dBm
0dB	36dBm	36dBm	26dBm
(*) DAS Tray operating temperature			

d Select the TDTPOI operation mode from the **Preset** drop-down list.


The Preset options set the module operating mode as detailed in the diagrams below:

► **Dual SISO**

Simplex Base Station without Diversity:




Duplex Base Station without Diversity:




► **UMTS Div**

Simplex Base Station with UMTS Diversity:




Duplex Base Station with UMTS Diversity:




► **GSM Div**

Simplex Base Station with GSM Diversity:




Duplex Base Station with GSM Diversity:




► **MIMO 2x2**

Simplex Base Station with GSM Diversity:



Duplex Base Station with GSM Diversity:



- e Select the power limiter mode to protect the module.

The following options are available in the **Pwr Limiter mode** drop-down list:

- **RF OFF:** If the Power Limiter Mode is set to *RF OFF*, when the rms downlink input power exceeds the user-set maximum input signal threshold for the path (1 or 2), the Pwr Limiter DL (1 or 2) alarm is triggered and the path is switched off, until the alarm condition ceases (auto power-on).
- **10dB plus:** If the Power Limiter Mode is set to *10dB plus*, when the rms downlink input power exceeds the user-set maximum input signal threshold for the path (1 or 2), the Pwr Limiter DL (1 or 2) alarm is triggered and the path input power is reduced by 10dB, until the alarm condition ceases.

Note: When the rms downlink input power (path 1 or 2) exceeds either the user-defined maximum input signal threshold +10dB, or the allowed Absolute Maximum Input Power, the path (1 or 2) is switched off by the overdrive protection and the Pwr Overdrive DL (1 or 2) alarm is triggered.

The overdrive alarm needs to be cleared: when the alarm ceases, click the **Clear Overdrive** button to reset the path.

The path is restored @ max attenuations (Mec DL and Dig DL) and the re-commissioning of the path is required.

- f Set the Power Alarm **Hysteresis** to avoid repeated power alarm reports.

If the input power exceeds the maximum input power threshold set for the path, the power limiter alarm is triggered.

The alarm is cleared when: $DL\ RMS\ power\ [dBm] = DL\ max\ RMS\ thrs - Power\ Alarm\ Hysteresis$

4. Click the yellow save icon to save changes for each module.

Commissioning TCPRIPOIs

1. In the **Settings** menu, select **Massive Change Menu**.
2. In the **POI CPRI** pane, click the **Massive Change** button to display the massive change table for TCPRIPOIs.

Massive Change for POI CPRI

Massive Change for POI CPRI

Modules

All

All

All

Address	Code	Name	Path	DL att [dB]	UL att [dB]	DL RMS power [dBm]	Save	Reload
<div><div></div>1.12.8</div>	TCPRIPOI-19-M	TCPRIPOI-19-M_51	1	29	17	-29.1	<div><div></div></div>	<div><div></div></div>
			2	16	17	-27.6	<div><div></div></div>	<div><div></div></div>

3. In the Massive Change table configure each TCPRIPOI as follows:

- a Assign a name to the component.
- b Adjust uplink and downlink attenuation for each path.

After successful completion of relevant training courses, use the commissioning tool spreadsheet, provide by JMA, to calculate uplink and downlink attenuation to be set.

Massive change label	Default setting (maximum)
UL att	25dB
DL att	30dB

4. Click the yellow save icon to save changes for each module.

Commissioning Remote Units

1. In the **Settings** menu, select **Massive Change Menu**. In the **Massive Change Menu** panel, remote units are grouped by type.
2. Click the **Massive Change** button to display the Massive Change table for the remote units of the same type.

Note: The operating bands and output power of Software Defined Remote Units (SDRU) are tied to license keys, which can be managed remotely using the *JMA Wireless SDRU Panel* software.

In the Massive Change table for SDRUs, unlicensed channels are locked. If not all the expected channels and output power levels are available for commissioning, verify the activation of purchased features. Refer to the *JMA DAS Platform SDRU Panel User Guide* for details.

3. In the Massive Change table configure each remote unit as follows:

- a Assign a name to the remote unit.
- b Check the downlink output power (*DL Pwr*).
- c If necessary, increase the DAS attenuation.
- d Enable RF.
- e Enable Downlink power alarms.

4. Repeat steps 2 and 3 for all the types of remote units installed in the DAS.

5. Click the yellow save icon to save changes for each unit.

Note: The Massive Change table for medium power (1.25W-to-2W) Software Defined Remote Units (SDRUs) provides additional tools to temporary unlock unlicensed bands for RF testing purposes.

Massive Change for Medium Power Software Defined RU
Massive Change for Medium Power Software Defined RU

Channel Status Legend

- Unlicensed channel - Temporary DL mode (@ max output power)
- Unlicensed channel - Temporary UL mode
- Unlicensed channel

Action on all SDRU

- DL Unlock
- UL Unlock
- DL/UL Restore

Modules

Address	Code	Name	RF enable	Channel	Enabled output pwr [dBm]	DL att [dB]	UL att [dB]	DL pwr [dBm]	DL pwr low	DL pwr high	Timer (hh:mm)	Actions	Save	Reload
1.11.1.3	TRX7C8918212...	TRX7C89182126AT_		700EU + LT...	OFF						00:00	DL Unlock UL Unlock DL/UL Restore		
				EGSM900	OFF									
				DCS1800	OFF									
				UMTS2100	OFF									
				LTE2600	OFF									
				700EU + LT...	OFF									
1.11.3.1	TRX7C8918212...	TRX89182126AT		EGSM900	30	10	15	-19.4			00:00	DL Unlock UL Unlock DL/UL Restore		
				DCS1800	33	10	15	-21.7						
				UMTS2100	OFF									
				LTE2600	OFF									
				700EU + LT...	30	0	0	-18.7						
				EGSM900	OFF									
				DCS1800	OFF									
				UMTS2100	30	0	0	-21						
				LTE2600	OFF									
1.12.1...	TRX7C8918212...	TRX7C89182126AT		700EU + LT...	30	0	0	-18.7			00:00	DL Unlock UL Unlock DL/UL Restore		
				EGSM900	OFF									
				DCS1800	OFF									
				UMTS2100	30	0	0	-21						
				LTE2600	OFF									

DAS Commissioning

You can apply the temporary unlock to either a single SDRU (buttons in the **Actions** column of the Massive Change table) or to all the SDRUs listed in the Massive Change table (buttons in the **Action on all SDRU** pane).

- Click **UL Unlock** to activate the UL path for unlicensed bands.
In the Massive Change table, the row background color of unlicensed channels turns blue and the **Timer** displays the time elapsed since unlock.
- Click **DL Unlock** to activate the DL path for unlicensed bands (@ maximum output power).
In the Massive Change table, the row background color of unlicensed channels turns orange and the **Timer** displays the time elapsed since unlock.
- Click **DL/UL Restore** to restore original licenses configuration and reset the timer.
The row background color of unlicensed channels turns gray.

Note: The temporary unlock can be repeated.

RF Commissioning of Donor Front Ends (TDFEs)

The parameters for the commissioning of Donor Front Ends (TDFEs) must be set individually for each component.

1. In the **Physical Tree**, select the Donor Front End to display its details panel.
2. Assign a name to the Donor Front End.
3. In the **Parameters** pane:
 - a Select the *Preset* corresponding to the DAS configuration for automatic gain setting.

- b Select the Digital Filter *Selectivity* (Standard TDFE modules only).

The *Selectivity* options allow the filter to be optimized either for low delay (*UMTS*) or for high selectivity (*GSM 95dB*).

The following options are available:

- *GSM 95dB* is the most selective filter.
 - *GSM 80dB* is a less selective filter, introducing little bit less delay, as compared with the *GSM 95dB* option.
 - *UMTS* is optimized for introducing the lowest delay.
- c Select the SFE/RU output power in the *Max Gain* drop-down list to display the proper downlink diagram in the Spectrum panel
4. In the **Common-Uplink** and **Common-Downlink** panes, adjust Uplink (UL) and Downlink (DL) attenuation for each path.

DAS Commissioning

Common - Uplink		Common - Downlink	
Pwr Out UL [dBm]	-26,7	Pwr In DL [dBm]	-81,6
Att Module UL [dB]	30	Att Module DL [dB]	0
Pwr Out UL	●	Pwr Out DL	●
Peak Pwr + OFA UL	●	Peak Pwr + OFA DL	●
Lock Detect UL	●	Lock Detect DL	●
ALC On UL	●	ALC On DL	●
Pwr In UL	●	Pwr In DL	●

After successful completion of relevant training courses, use the commissioning tool spreadsheet, provide by JMA, to calculate uplink and downlink attenuation to be set.

Description	Web page label	Default setting
Uplink Digital Attenuation	Att Module UL	30dB
Downlink Digital Attenuation	Att Module DL	30dB

5. In each sub-band pane:

- Adjust Uplink and Downlink attenuations (Att Module UL and Att Module DL).
- Set the Uplink Frequency band center (Frequency UL) and Bandwidth for each sub-band to be enhanced.
- Enable Uplink and Downlink for the sub-band.

Sub-band 1 Uplink		Sub-band 1 Downlink	
UL Enabled	<input checked="" type="checkbox"/>	DL Enabled	<input checked="" type="checkbox"/>
Pwr Out UL [dBm]	-18,9	Pwr In DL [dBm]	-51,3
Att Module UL [dB]	0	Att Module DL [dB]	15
Pwr Out SB1 UL	●	Pwr In SB1 DL	●
		Pwr Min SB1 DL	●
Frequency UL [MHz]	1947		
Bandwidth [MHz]	0,2		
Frq Range [MHz]	1946.90 - 1947	Frq Range [MHz]	2136.90 - 2137
Filter ID	0		

6. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save all the changes in the page.

Enabling Downlink RF Power Alarms

After completing the previous steps, it is strongly recommended to check that all the Downlink RF power alarms are enabled.

Enabling and Disabling Alarms

Alarms can be enabled or disabled in the detail panel of each component as follows:

- In the **Physical Tree**, select the DAS component to display its details panel.
- In the **Toolbar**, select the **Advanced** tool to display check boxes next to the alarm icons.
- Select the check box next to an alarm to enable the alarm. The **Save** tool in the toolbar turns yellow.
- To disable an alarm, deselect the check box. The Save tool in the toolbar turns yellow.

Note: If an alarm is disabled, the icon is always green.

- Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Advanced tool

When selected, enabled/disabled checkboxes are displayed next to alarm icons.

Configuration read from device 2018-05-31 12:54:28

1.13.2 TDTPOI (TDTPOI-19-D)
DAS TRAY PCS 1900 Dual

Identification		Alarm summary	
Type hex	00002E	Communication state	●
Model hex	00000000105	Max severity	●
Version	10	Active Alarms	0
Serial Number	140551357		

Description

Name: DasTray

Parameters			
Preset	Dual SISO	LNA1 Current	●
Mains Fault	●	LNA2 Current	●
		Temperature [°C]	32.2
		Low Temperature	●
		High Temperature	●

Enable/disable checkbox

When selected, the alarm is enabled. If the alarm is disabled the icon is always green

Setting External Alarms and Relays





External Alarms

Alarms generated by external devices can be connected to the external alarms input connector (EXT IN), available on the following DAS components:

- Supervision module (**TSPV**)
- Alarm Board
- Remote units (**RU**)
- Next Generation remote units (**NG RU** and **NG SDRU**)

Configure and enable monitoring of external alarms as follows:

1. In the **Physical Tree**, select the DAS component to display its details panel.
2. In the **External alarms** table, assign names, severity (*Critical, Major, Minor, Warning*), and polarity (*active-high* or *active-low*) to the alarms.

External alarms					
Name	Enable	Severity	Polarity	State	
Ext. name 1	<input checked="" type="checkbox"/>	warning ▼	active-low ▼		
Ext. name 2	<input checked="" type="checkbox"/>	warning ▼	active-low ▼		
Ext. name 3	<input checked="" type="checkbox"/>	warning ▼	active-low ▼		
Ext. name 4	<input checked="" type="checkbox"/>	warning ▼	active-low ▼		

3. Select the **Enable** check box to enable monitoring of configured external alarms.
4. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save all the changes in the page.

Relays

The EXT OUT connector is available on the following DAS components:

- Supervision module (TSPV)
- Remote units (RU)

Configure the logic of the relays in the **Relays** pane, available on the supervision module (TSPV) and remote units detail panels.

Supervision Module (TSPV)

The screenshot shows the 'Relays' configuration panel for the Supervision Module (TSPV). A dropdown menu is open, displaying a list of policy options. The options are categorized into 'Manual operation' and 'Automatic options'. The 'Automatic options' list includes various alarm event combinations such as 'CRT All', 'CRT+MJR All', 'CRT+MJR+MIN All', 'CRT+MJR+MIN+WRN All', 'CRT only master', 'CRT+MJR only master', 'CRT+MJR+MIN only master', 'CRT+MJR+MIN+WRN only master', 'CRT only remote', 'CRT+MJR only remote', 'CRT+MJR+MIN only remote', and 'CRT+MJR+MIN+WRN only remote'. Below the menu, a table is visible with columns 'Name', 'NC/NO', and 'State'. The table contains four rows, all with 'Manual' in the 'Name' column and 'OPEN' in the 'State' column.

1. In the **Physical Tree**, select the supervision module to display its details panel.
2. In the **Relays** pane, assign a descriptive name to the relay.
3. From the **Policy** menu, select either the *Manual* or an automatic mode.

- *Manual*: The relay is switched manually by the operator.
 - a Select the relay status, *Open* or *Closed*.
- Automatic mode: The relay is triggered automatically by alarms occurring in the DAS.
 - a Select one automatic option from the list of predefined triggering alarm events:

When the *CRT+MJR+MIN+WRN All* option is selected, alarms are not filtered: the relay is triggered when an alarm arises in any component of the DAS.

The other predefined triggering events filter alarms by device type and alarm severity:

Alarm severity filter:

CRT+MJR+MIN (Critical + Major + Minor) – The relay is triggered when an alarm with a severity level equal to, or higher than Minor arises.

CRT+MJR (Critical + Major) – The relay is triggered when an alarm with a severity level equal to, or higher than Major arises.

CRT (Critical) – The relay is triggered when an alarm with a severity level equal to Critical arises.

Device type filter:

only master – The relay is triggered when an alarm arises in any component of the master unit.

only remote – The relay is triggered when an alarm arises in a remote unit.

b Set the relay status (NC/NO):

NO: the relay closes when the alarm condition selected in the Policy menu occurs.

NC: the relay opens when the alarm condition selected in the Policy menu occurs.

4. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Note: The policy and relay state are applied after the relay is triggered by an alarm.

Remote Units

Relays		
Name	Policy	State
	Manual ▼	CLOSED ▼
	Manual ▼	CLOSED ▼
	Manual ▼	CLOSED ▼
	Manual ▼	CLOSED ▼

You can manually switch the external outputs of remote units as follows:

- 1.** In the **Physical Tree**, select the remote unit to display its details panel.
- 2.** In the **Relays** pane, assign a descriptive name to the relay.
- 3.** From the **State** drop-down list, select *Open* or *Closed*.
- 4.** Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save all the changes in the page.

Setting Alarm and Heartbeat Notifications

SNMP traps and SMS alerts can be forwarded to periodically test the system availability and to alert operators when alarm events occur in the DAS.

Enabling SNMP Traps

- 1. In the **Settings** menu, select **Notifications** to access the **Notifications** panel.
- 2. From the **Trap mode** drop-down list, in the **Traps** pane, select either *SNMPv2c* or *SNMPv3* to enable alarm notifications to be sent out.

Heartbeat

Last sent2023-05-03 00:01

Interval (hours)12

Traps

Trap modeSNMPv2c

Trap mode

Trap notifications can be enabled to alert operators when alarm events occur in the DAS.

- 3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Setting Heartbeat Notifications

- 1. In the **Heartbeat** pane, set the time **Interval (hours)** between heartbeat notifications.
- 2. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Note: When the heartbeat interval is set to 0 (zero) heartbeat notifications are disabled.

Heartbeat

Last sent2023-05-03 00:01

Interval (hours)12

Traps

Trap modeSNMPv2c

- Heartbeat
- *Last sent*: date and time of the last Heartbeat message sent.
 - *Interval*: time interval (hours) between KeepAlive messages. When the Interval is set to 0 (zero) KeepAlive notifications are disabled.

Setting Alarms and Heartbeat Trap Destinations

In the **Trap notifications** table, you can set up to five trap destinations to receive SNMP notifications.

- 1. Add each trap receiver as follows:
 - a Set the **IP address** and **Port** of the SNMP trap destination.
- Note:** When the DAS is part of a Network managed via JMA Operation Management Centre (OMC), the OMC Server IP address can be set as one of the recipients of the SNMP trap notifications, in

order to optimize the alarm monitoring of the DAS (refer to the *OMC Software Installation and Configuration Guide*).

- b** Select the **User/Community** that is sending the trap (SNMPv3 Trap Mode only).
- c** From the **Alarm severity** drop-down list, select the minimum alarm severity for notifications to be sent out. Only the events of equal or higher severity level cause the trap notification to be sent out.
- d** Select the **Alarm** check box to enable SNMP traps to be forwarded to the trap destination.
- e** Select the **Heartbeat** check box to enable heartbeat notifications to be forwarded to the trap destination.

TRAP notifications					
IP address	Port	User	Alarm	Alarm severity	Heartbeat
0.0.0.0	162	admin	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
0.0.0.0	162	admin	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
0.0.0.0	162	admin	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
0.0.0.0	162	admin	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
0.0.0.0	162	admin	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
IP address	Port	User	Alarm	Alarm severity filter	Heartbeat
IP Address and port of each SNMP trap destination		User that is sending the trap (SNMPv3 Trap Mode)	Enable/disable alarm notifications	A minimum alarm severity level can be associated with each notification: only the alarms of equal or higher severity level cause the notification to be sent out.	Enable/disable heartbeat notifications

- 2.** Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Setting SMS Notifications






In the **SMS notifications** table, you can set up to five operators' phone numbers to receive SMS alarm and heartbeat notifications.


1. In the **Settings** menu, select **Notifications** to access the **Notifications** panel.

SMS notifications			
Operator number	Alarm	Alarm severity	Heartbeat
+393249500000	<input checked="" type="checkbox"/>	warning ▼	<input checked="" type="checkbox"/>
+000000000000	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
+000000000000	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
+000000000000	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>
+000000000000	<input type="checkbox"/>	warning ▼	<input type="checkbox"/>

<div>⚙️ Preferences</div>			
Operator number	Alarm	Alarm severity filter	Heartbeat
Phone numbers set as SMS recipients for alarm notifications	Enable/disable SMS notifications check box	A minimum alarm severity level can be associated with each notification: only the alarms of equal or higher severity level cause the SMS notification to be sent out	Enable/disable heartbeat notifications

2. Add each SMS recipient as follows:
 - a In **Operator number**, insert the recipient's phone number.
 - b From the **Alarm severity** drop-down list, select the minimum alarm severity for SMS notifications to be sent out. Only the events of equal or higher severity level cause the notification to be sent out.
 - c Select the **Alarm** check box to enable SMS notifications.
 - d Select the **Heartbeat** check box to enable heartbeat notifications.
3. Click the **Preferences** button to select information to be included in the SMS (*Notification fields*) and to select the SMS notification format preferences (*Notification format*).

 Save
  Advanced
  Print
  admin
  Logout



SMS Notifications Preferences

Manage SMS notifications configuration

Notification fields

Field	Display on active	Display on ceased
System name	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Module type	<input type="checkbox"/>	<input type="checkbox"/>
Module type name	<input type="checkbox"/>	<input type="checkbox"/>
Module address	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Module name	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Module description	<input type="checkbox"/>	<input type="checkbox"/>
Alarm name	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Alarm id	<input type="checkbox"/>	<input type="checkbox"/>
Alarm severity name	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Alarm severity id	<input type="checkbox"/>	<input type="checkbox"/>
Alarm start/end time	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Notification format

Multiple notifications per sms
 ☒

Field separator

Field header
 ☒

- Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Setting the Network Security

1. In the **Settings** menu, select **Services and Security**.
2. Enable or disable network services to set the appropriate security level for the supervision module communication interfaces.

In the **Services** table, colored icons indicate the security level of each service:

- Orange: unsafe service.
- Cyan: safe but not necessary service.
- Green: safe service.

In the **Security overview** pane, the color-coded icon provides an at-a-glance view of the network security status.

3. Enable or disable incoming ping for the supervision module communication interfaces.
4. Click the yellow **Save** tool or press the **Enter** key on your keyboard to save all the changes in the page.

Setting a Secure Network

1. For a secure network, configure services as shown in the following figure:

Services and Security
Firewall, network services and ports configuration

Firewall | **Security overview**

Firewall active ● Current situation ●

Service	Protocol	Port	Security
File Transfer	SFTP	22	●
Shell mode	SSH	22	●
Web access	HTTPS	443	●
SNMP	SNMPv3	161	●
Tunnel	Tunnel	5556	●

Incoming Ping

Interface	Allowed
WAN	<input type="checkbox"/>
LAN	<input checked="" type="checkbox"/>
VPN	<input type="checkbox"/>

SNMP

Alarm table entries Active + Ceased ▼

2. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Note:


If the *Tunnel* is disabled (OFF), the DAS cannot be managed via JMA OMC nor can Software Defined Remote Units (SDRUs) feature configuration and licensing be performed via the SDRU Panel.

The web server accepts only Secure HTTP (HTTPS) connections: make sure to use port 443 to communicate with the supervision module.

Setting the System Date and Time


1. In the **Settings** menu, select **Date and Time**.
2. From the **Synch Mode** drop-down list, select the synchronization mode:
 - a Select *No synch* to manually set the DAS date and time.

In the **Change board time** pane, enter the board date and time in Local Time Standard.



The screenshot shows the 'Date and Time' settings interface. At the top left is a clock icon. To its right, the title 'Date and Time' is displayed in blue, with the subtitle 'Date, Time and Synchronization settings' in a smaller font. Below this, there are two main sections: 'Synch mode' and 'Change board time'. The 'Synch mode' section has a dropdown menu currently set to 'No synch'. The 'Change board time' section contains two input fields: 'Date (yyyy-mm-dd)' with the value '2017-10-04' and 'Time (hh:mm:ss)' with the value '19:49:16'.

- b Select *NTP* to enable and configure the automatic clock synchronization service.
 - Enter the NTP Server IP address in the **NTP Server** field.
 - In the **Synch Interval** field, set the time interval (minutes) between automatic time synchronization.
 - Click **Synchronize now** to check the NTP Server availability.



This screenshot shows the 'Date and Time' settings interface with the 'Synch mode' dropdown set to 'NTP'. The 'Change board time' section is no longer visible. Instead, an 'NTP Settings' section is shown, containing three input fields: 'NTP Server' with the value '10.150.0.56', 'NTP Port' with the value '123', and 'Synch Interval (min)' with the value '60'. At the bottom of this section is a dark blue button with a circular refresh icon and the text 'Synchronize now'.

3. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Setting Options for Testing the Network Connection

You can set up to five IP Addresses to periodically test the network connection as follows:

1. In the **Settings** menu, select **Communication**.
2. In the **Ping settings** pane, set the **Ping interval** between ping attempts.
Note: The ping interval is set as a global ping configuration option.
3. In the **Ping Address Table**, select the connection to be tested from the **Interface** drop-down list.
4. Set the **IP Address** for the network connectivity test.
5. Select the **Enabled** check box.
6. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Note: JMA recommends that you set at least one IP address always available because if the ping test fails, the network interface will be restarted.

An example of the **Ping Address Table** with configured IPv4 addresses is shown in the following figure:

The screenshot shows the 'Ping settings' window. At the top, there's a blue header 'Ping settings'. Below it, 'Ping interval (minutes)' is set to 1. The 'Ping Address Table' is a table with three columns: 'Ip Address', 'Interface', and 'Enabled'. It contains five rows of IPv4 addresses: 10.150.5.171, 192.168.0.5, 192.168.1.123, 8.8.8.8, and 192.168.0.5. Each row has a dropdown menu for the interface (all set to 'wan' or 'wwan') and an unchecked 'Enabled' checkbox.

Ip Address	Interface	Enabled
10.150.5.171	wan	<input type="checkbox"/>
192.168.0.5	wan	<input type="checkbox"/>
192.168.1.123	wan	<input type="checkbox"/>
8.8.8.8	wwan	<input type="checkbox"/>
192.168.0.5	wwan	<input type="checkbox"/>

An example of the **Ping Address Table** with configured IPv6 addresses is shown in the following figure:

The screenshot shows the 'Ping settings' window. At the top, there's a blue header 'Ping settings'. Below it, 'Ping interval (minutes)' is set to 10. The 'Ping Address Table' is a table with three columns: 'Ip Address', 'Interface', and 'Enabled'. It contains five rows of IPv6 addresses: 2002:c000:203::4, 2002:c000:203::5, and three rows of empty addresses (indicated by '..'). Each row has a dropdown menu for the interface (all set to 'eth0') and an unchecked 'Enabled' checkbox.

Ip Address	Interface	Enabled
2002:c000:203::4	eth0	<input type="checkbox"/>
2002:c000:203::5	eth0	<input type="checkbox"/>
..	eth0	<input type="checkbox"/>
..	eth0	<input type="checkbox"/>
..	eth0	<input type="checkbox"/>


Setting the Supervision Module Communication Interface for Remote Management

After the commissioning of the DAS is complete, configure the DAS communication interface for remote management.

Setting the WAN Interface

1. Contact the Network Administrator to get the parameters for the configuration of the supervision module WAN interface.
2. In the **Settings** menu, select **Communication**.
3. In the **WAN Parameters** pane, select the IP (Internet Protocol) version, IPv4 or IPv6, from the *IP version* drop-down list.

Note: To avoid connection issues, JMA strongly recommends to switch from IPv4 to IPv6, or vice versa, only when connected locally to the supervision module LAN port.



WAN Parameters			
MAC Address	9C:53:CD:03:11:9D	Wan State	●
IP Version	IPv4 ▼	Netmask	255.255.255.0
IPv4 Address	10.150.4.192	Gateway IPv4	10.150.4.253
DNS Address		MTU	1500

4. Enter the information provided by the Network Administrator to configure the connection.
5. Set the WAN *MTU*, Maximum Transmission Unit size, if necessary.
6. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save all the changes in the page and allow redirection to the new IP address.
7. Connect the Wide Area Network (WAN) to the supervision module WAN port, to allow the remote management of the DAS.



Caution: Never connect the Wide Area Network to the LAN port. The DHCP server, running on the LAN port, may cause connectivity issues in the Wide Area Network.

Setting the Wireless WAN Interface (Modem)

1. In the **Settings** menu, select **Communication**.
2. In the **Modem Parameters** pane, select the **Modem preferences** button to access the modem configuration parameters.

Note: To reboot the modem and restart the WWAN connection, click the **Modem commands** button. A simple terminal for sending AT commands to the modem is also available.

3. Configure the wireless connection and APN preferences.

Modem Preferences
Manage modem configuration

SIM card settings

IMSI: 222015704125498 **Lock SIM**

ICCID: 89390100002242746893

Mobile connection settings

Data connection enabled ☒ MTU: 1500

APN profile: Operator **APN preferences** Use IPv4 only ☒

Service mode: Auto Long SMS allowed ☒



Preferred technology: 3GPP WWAN Internet test ☐

WWAN Internet test time peri...: 300

4. Select the **Data connection enabled** check box to enable the wireless connection.
5. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save changes.

Setting the VPN

The VPN Client available on the supervision module allows a secure access to the DAS over unsecured networks (such as the Internet).

VPN Parameters			
VPN enabled	<input checked="" type="checkbox"/>	VPN State	
Server IPv4 address	<input type="text" value="46.44.238.53"/>	IPv4 Address	<input type="text" value="10.96.0.3"/>
Server port	<input type="text" value="1196"/>	Netmask	<input type="text" value="255.255.0.0"/>
VPN Device	<input type="text" value="tun0"/>	MTU	<input type="text" value="1500"/>
 Upload VPN keys			

1. In the **Settings** menu, select **Communication**.
2. Select the **VPN Device** type (Tap or Tun).
3. Enter the VPN server IPv4 address and port.
4. Set the VPN MTU, Maximum Transmission Unit size, if necessary.
5. Upload VPN keys (Certification Authority, Client Certificate, Client Key), if needed.
6. Select the **VPN enabled** check box to enable the VPN connection.
7. Click the yellow **Save** tool in the toolbar or press the **Enter** key on your keyboard to save all the changes in the page and apply the new VPN settings.
8. Check that the **VPN State** icon turns green within a few seconds.

Note: The IP Address allocated by the VPN Server to the VPN Client is displayed in the IPv4 Address field.


Managing Users

Users with **admins** role permissions can manage their own account and other user accounts.

Editing and Deleting Existing Accounts

1. In the **Settings** menu, select **Users** to open the **Users** panel.
2. In the **User table**, click **Edit** to edit accounts.
3. Click **Delete** to delete accounts.

NOTE: At least one account with administrative permissions (admins role) must be present and cannot be deleted.




Users








List all information about the users of the system

User information

Your name
Your role

Commands

 Add new user


User table					
Username	Community	SNMPv3 Authentication	SNMPv3 Privacy	Edit	Delete
admin	admins	SHA	AES	 Edit	
guest	guests	SHA	AES	 Edit	 Delete
superuser	superusers	SHA	AES	 Edit	 Delete
user	users	SHA	AES	 Edit	 Delete

Info

Admins: total control over all parameters
Superusers: control over all parameters but users table
Users: control over modules parameters, no SPV
Guests: can read but not edit parameters of the system

Adding a New User

1. In the **Settings** menu, select **Users** to open the **Users** panel.
2. In the **Commands** pane, click **Add new user**.
3. Enter the new user name in the **User name** field.



[Add a new User](#)
 Create a new user account

User information

User name

User role

users

Password for login and SNMPv3 authentication

SNMPv3 Authentication

SHA

Auth Password

Confirm Auth Password

Password for SNMPv3 privacy

SNMPv3 Privacy

AES

Privacy Password

Confirm Privacy Password

Note:

Admins: total control over all parameters

Superusers: control over all parameters but users table

Users: control over modules parameters, no SPV

Guests: can read but not edit parameters of the system

4. Select a role for the new user from the **User role** drop-down list.

The following table lists the capabilities associated with each role and the factory-set username and password for each role:

User Role (Community)	Factory-set Username and Password	Capabilities
admins	User name: admin Password: Password1	Total control over all parameters.
superusers	User name: superuser Password: Password1	Control over all parameters except users table.
users	User name: user Password: Password1	Control over modules parameters, no supervision (SPV).
guests	User name: guest Password: Password1	Can read but not edit parameters of the system (read-only user).

5. Enter the user's password for login and SNMPv3 authorization twice, both in the **Auth Password** field and in the **Confirm Auth Password** field.

Password Requirements

Passwords must be at least eight characters long and must contain characters from the following categories:

- lowercase letters (a through z)
- uppercase letters (A through Z)
- base 10 digits (0 through 9)

The user's input validation feature warns users if invalid characters are entered and details what input is expected for the field.


Creating and Managing Inventory Lists

When commissioning is complete, JMA strongly recommends that you create an Inventory list to back up the DAS configuration.

Note: Existing inventory lists are cleared when a new **Discovery full** is accepted. See "[Discovering the DAS Components](#)" on page 9.

Creating an Inventory List of the DAS Current Configuration


- 1. In the **Settings** menu, select **Inventory**.
- 2. In the **Other Commands** pane, click **Create new inventory**.



Note: Inventory tasks, or web pages download, made by a user are shared with the other connected users, whose activity will stall until the operation is complete.

Selecting an Inventory List

1. In the **Settings** menu, select **Inventory**.
2. In the **Selected Inventory** pane, select a list from the **Select Inventory (UTC)** drop-down list. The selected inventory list displays in the **Selected Inventory Table**.



Inventory
 List of the modules of the system

Selected Inventory

Other commands

Select Inventory (UTC) 2017-11-20,08:28:29

Create new inventory

Download inventory (.csv)

Delete current

Download web pages (.tgz)

Selected Inventory Table


Address	Type hex	Model hex	Version	Vendor	Serial number	Commercial code	Info
0	0000FC	000000030A35	4.0.1	0	-	-	Details
1.1.1	00004A	000000000001	2	0	1007523004	TSPV-EBB	Details
1.1.3	000003	000000003231	14	0	1003546134	TTRU4W-S-M	Details
1.1.3.1	000036	00000000AF21	12	0	1001900001	T7S8SC8A19AWEDWDT	Details
1.1.5	000003	000000003231	14	0	1004189112	TTRU4W-S-M	Details
1.1.5.2	000024	000000002F09	11	0	1008256028	T7S8SC8A19AWEWVAS	Details
1.1.7	000003	000000003231	14	0	1004185212	TTRU4W-S-M	Details
1.1.7.1	000024	000000002F09	12	0	1008194002	T7S8SC8A19AWEWVAS	Details
1.1.7.2	000024	000000002F09	12	0	1008194012	T7S8SC8A19AWEWVAS	Details
1.1.7.3	000027	00000000742D	5	0	1006937075	TRL7S8SC8A19AW23AT	Details

After an inventory is selected:

- You can click **Download inventory (.csv)** to download the selected inventory list in csv (Comma Separated Value) format.
- You can click **Download Web Pages (.tgz)** to download a compressed file (.tgz format), containing the selected inventory list web pages. Extract files to a folder to browse offline web pages.
- In the green bar at the top of each device main panel, the **Inventory** button is available for authorized users to restore the device configuration from the selected inventory list. Refer to the *JMA DAS Platform Remote Monitoring and Management User Guide* for details.

Downloading Inventory Lists (csv Format)

1. When different inventory lists are available, select an inventory list from the **Select Inventory (UTC)** drop-down list. The selected inventory displays in the **Selected Inventory Table**.



Inventory
List of the modules of the system

Selected Inventory | **Other commands**

Select Inventory (UTC) 2017-11-20,08:28:29

Download inventory (.csv) | Create new inventory

Download web pages (.tgz) | Delete current

Selected Inventory Table

Address	Type hex	Model hex	Version	Vendor	Serial number	Commercial code	Info
0	0000FC	000000030A35	4.0.1	0	-	-	Details
1.1.1	00004A	000000000001	2	0	1007523004	TSPV-EBB	Details
1.1.3	000003	000000003231	14	0	1003546134	TTRU4W-S-M	Details
1.1.3.1	000036	00000000AF21	12	0	1001900001	T7S8SC8A19AWEDWDT	Details
1.1.5	000003	000000003231	14	0	1004189112	TTRU4W-S-M	Details
1.1.5.2	000024	000000002F09	11	0	1008256028	T7S8SC8A19AWEWVAS	Details
1.1.7	000003	000000003231	14	0	1004185212	TTRU4W-S-M	Details
1.1.7.1	000024	000000002F09	12	0	1008194002	T7S8SC8A19AWEWVAS	Details
1.1.7.2	000024	000000002F09	12	0	1008194012	T7S8SC8A19AWEWVAS	Details
1.1.7.3	000027	00000000742D	5	0	1006937075	TRL7S8SC8A19AW23AT	Details

2. Click **Download inventory (.csv)** to download the selected inventory list in csv (Comma Separated Value) format.

Downloading Inventory Lists (Web Pages)

1. When different inventory lists are available, select an inventory list from the **Select Inventory (UTC)** drop-down list. The selected inventory displays in the **Selected Inventory Table**.
2. Click **Download Web Pages (.tgz)** to download a compressed file (.tgz format), containing the selected Inventory list web pages.
3. Extract files to a folder to browse offline web pages.

Getting Help: Technical Support Contact Information

- JMA International
+1 315 431-7100
+1 888-201-6073
customerservice@jmawireless.com
- JMA United States
Toll Free +1 888-201-6073, Outside US +1 315-431-7100
techsupport@jmawireless.com
- JMA Italy - BTC
+39 051 6946811
VAS-techsupport@jmawireless.com

Abbreviations

AGC

Automatic Gain Control

APN

Access Point Name

BS

Base Station

CPRI

Common Public Radio Interface

CSV

Comma Separated Value

DAS

Distributed Antenna System

DHCP

Dynamic Host Configuration Protocol

DL

Downlink

EU

European Union

FQDN

Fully Qualified Domain Name

HTTP

Hypertext Transport Protocol (<http://>)

HTTPS

secure Hypertext Transport Protocol (<https://>)

IPv4

Internet Protocol version 4

IPv6

Internet Protocol version 6

Abbreviations

ITE

Information Technology Equipment

LAN

Local Area Network

LMT

Local Maintenance Terminal

MIMO

Multiple Input, Multiple Output

MU

Master Unit

NEM

Network Element Manager

NG

Next Generation

NTP

Network Time Protocol

PDU

Power Distribution Unit

Pol

Point of Interface

PSU

Power Supply Unit

RAL

Restricted Access Location

RU

Remote Unit

SDRU

Software Defined Remote Unit

SISO

Single Input, Single Output

Abbreviations

SMS

Short Message Service

SNMP

Simple Network Management Protocol

SSB

Synchronization Signal Block

Syslog

System Logging Protocol

TCP

Transmission Control Protocol

TDD

Time Division Duplex

TDFE

Digital Donor Front End

UDP

User Datagram Protocol

UK

United Kingdom

UL

Uplink

UPS

Uninterruptible Power Supply

UTC

Universal Time Coordinated

VPN

Virtual Private Network

WAN

Wide Area Network

WDM

Wavelength Division Multiplexing

Abbreviations

WWAN

Wireless Wide Area Network