


UXP-DX-158



For 1-5/8" Annular Connectors



	Connector Models Supported	
	Interface	7-16 DIN
	Male	UXP-DM-158
	Female	UXP-DF-158



[Scan for install video](#)

Tools/Materials Required				
Power drill	SP-158 Prep/strip tool	HCG-CC (RP240 / RP210-B / RP100-B)	Frameset	TQ-114-F18 (DIN 7-16)
			 UPDATE IMAGE Refer to Step #3	
	RDCUTTER	Adjustable wrench	Alcohol wipe (included with connector)	
				

Step #1: Prep



Straighten cable and position RDCUTTER in valley of corrugation and cut off cable squarely.



Attach prep/strip tool to drill. Open blade lever and lock with pin. Insert cable and actuate drill.



Actuate drill until outer conductor reaches fixed stop; this will remove jacket.



Ensure blade is positioned over valley closest to end of cable. Release blade lever and actuate drill until cable is completely cut.



Blade lever is shown fully closed. Open lever, lock with pin, and remove tool. Two ridges should be visible.



Hold drill and prep stripping tool forward to eject the cable slug. Make sure any remaining cable is removed from tool.



Re-apply stripping tool to remove one more corrugation of jacket for three full visible ridges.




After stripping again, cable is ready for connector measurement marking. **Three full visible ridges** are acceptable. Ensure cut is made in the "valley."

UXP-DX-158

For 1-5/8" Annular Connectors



Step #2: Install



Align connector as shown with end of cap. Mark cable jacket (using pen or marker) in line with end of connector.



Use the provided alcohol wipe to clean the outer conductor. Push and twist connector onto cable until it reaches the cable mark.



Pull/push back the insert to allow connector/cable to lay flat in frame. Make sure connector is fully seated.

Step #3: Frameset options



Step #4: Compress



Press HCG tool trigger until gun cycles. Do not pull or push on tool or cable during compression.



After connector is fully compressed, connector will move away from alignment mark.



Add connector port seal (DIN female only) to ensure a moisture-proof connection. The port seal should sit in the flat area behind the threads.

Step #5: Torque



Stabilize connector with adjustable wrench and always be sure to torque the mating connector.

Interface Type	Torque Wrench	Torque	Hex Nut Size
DIN	TQ-114-F18	216 lbf-in (18 lbf-ft)	1-1/4"

Note: Use proper torque based on type of interface.

Cable Preparation Guide

Compare to picture to determine if correct cable prep was performed.
(For reference only)

